



**Plug&Share™**  
**Wireless USB Adapter**  
**54 Mbps 802.11g**

**6602G**

**Quick Start Guide**



Copyright © 2004 Advanced American Telephones. All Rights Reserved.  
AT&T and the Globe Design are trademarks of AT&T Corp., licensed to Advanced  
American Telephones. All marks are trademarks of their respective corporations.

## Package Contents



**Plug&Share™  
Wireless USB Adapter  
54 Mbps 802.11g**




**USB Cable**



**CD-ROM**  
Contains installation software, User Manual, Quick Start Guide and Safety & Warranty Information.

## Quick Start Guide

## Safety & Warranty Information



## System Requirements:

You must have a laptop or desktop computer with the following applications & hardware:

- Windows® 98 SE, Me, 2000 or XP
- Available USB port (USB 2.0 for optimum performance)
- Intel® Pentium II (or higher)
- 64 MB of RAM
- CD-ROM drive
- 5 MB of available hard-disk space (60 MB to load Adobe® Acrobat® Reader®)
- AT&T Plug&Share™ Wireless Router (or other 802.11b or g compliant router or access point)

AT&T Plug&Share™ Wireless USB Adapter 54 Mbps 6602G

### Before you begin


- If you have a Windows® XP or Windows® 2000 operating system, and you are installing this adapter on a PC you use at work, you must have “Administrator Rights”. This is normally determined by your IT person at work.
- If you have used an earlier AT&T 802.11b Series adapter (or one by another manufacturer), you must uninstall all drivers and utilities before installing your new adapter. If your system has a built-in wireless adapter, you must disable it before installing your new adapter.

### STEP 1: Install the Driver and Configuration Utility

- 1 **Do NOT install adapter first.** Insert the enclosed CD-ROM into your CD-ROM drive.
- 2 Your CD auto-run function may start automatically. If it does not, click on the **Start** button. Click **Run** and enter **D:\autorun**. (If your CD-ROM drive is not your D drive, use the appropriate drive letter.)
- 3 When the adapter menu screen appears, click on **Install Software** from the menu on the left side of the screen.
- 4 The InstallShield Wizard will appear.
- 5 Different versions of Windows® will present different screens. Press **Next** at each screen until driver installation has completed.
- 6 Some versions will present a screen that asks about restarting your computer. Choose **Yes, I will restart my computer now**.  
**IMPORTANT: Remove CD-ROM disk before continuing.**
- 7 Click **Finish**, if necessary. A new icon will appear on your Windows® desktop. Double-click it to launch the utility at any time.

**Proceed to Step 2 only after the software has been correctly installed.**

If correctly installed, a Utility icon (four vertical bars) should appear next to your computer's time display. An “X” indicates that software installation was successful, but the wireless adapter is not yet activated.



## STEP 2: Install the Wireless USB Adapter

Plug the adapter into a configured USB port in your computer (or use the supplied cable to connect it as shown at right).

## STEP 3: Recognize the Hardware


Depending on the Windows® operating system version running on your computer, one of several screens may appear to inform you that the computer recognizes new hardware. Choose to install the software automatically and click **Next**.

Depending on your Windows® version, you may see a Hardware Alert message or a Digital Signature Not Found message. Click **Continue Anyway** or **Yes** to complete the installation.

Depending on your Windows® version, you may have to restart your computer to complete the installation. If a Windows® message prompts you to restart your computer, do so.


Finally, some versions may display the message Systems Settings Change. Click **Yes**.

Check the indicator light to verify that the adapter is working: The light will remain on when receiving power and connected to the network. It will blink during data transfer.



## STEP 4: Configure the USB adapter for your wireless network

Check the **Utility** icon (four vertical bars) next to your computer's time display. If the bars are green, you are already connected and do not need to run the Wizard (skip to page 7). If the bars are not green within 30 seconds, double-click the **Utility** icon, then click the **Run Wizard** button at the next screen.




Double-click to run Utility. Number of green bars shows signal strength.


### Wizard screen 1

**SSID:** Enter the SSID (Service Set Identifier) used by your wireless router or access point. The default SSID is at&t. The SSID is case sensitive (i.e., "cat" and "Cat" are not the same). All wireless adapters on your network must use the same SSID as your wireless router and/or access point.

**WEP:** WEP is a form of wireless encryption. If you click **On** to enable WEP in your wireless adapter, you must turn on WEP in your router, and make sure all devices use the same settings.

 **CAUTION:** SSID and all WEP settings must be identical in all wireless network devices. WEP Ascii/Hex Key must match the WEP settings used in your router (may be called Security Phrase, Hex Key or other term).

Click **Apply** to save your settings and display Wizard screen 2 (see next page).



Wizard

The Wizard will help you to set up your adapter to connect to your wireless LAN.

The Wizard can also be used to restore the utility settings to the default values.

Please follow the wizard step-by-step to perform either task.

**RUN WIZARD**

Wizard

Enter the SSID for your wireless network. Set the WEP encryption fields so that they match your wireless router. Press Apply when done.

SSID  Enter up to 32 letters or numbers

WEP  On  Off

ASCII Key  Hex Key  Length

ASCII / Hex Key

**APPLY** **CANCEL**

## Wizard screen 2

This screen shows the status of your network connection.

Your adapter should have found the network associated with the SSID you entered, and automatically set the channel to agree with your wireless router and/or access point. If you see Pass in the top two fields on this screen, you are ready to close this window and begin using your wireless network. Test this by visiting the Internet (see next page).

You can view or change the adapter setting from the other screens. Just click on the tabs in the blue menu bar at the top of this screen.

The screenshot displays the 'Wizard' screen for a USB Adapter. At the top, there is a navigation menu with tabs: '> Wizard', 'Link Info.', 'Configuration', 'Security', 'SiteSurvey', and 'About'. Below the menu is a header area with a background image of a person using a laptop, the text 'USB Adapter', and 'AT&T PLUG&SHARE™ DATA NETWORKING PRODUCTS'. The main content area is titled 'Wizard' and contains the following information:

- Wireless Network Connection :
- Internet Connection :
- Link Quality/Signal Strength**
  - Link Quality: 100% (represented by a full black progress bar)
  - Signal Strength: 62% (represented by a black progress bar that is approximately 62% full)
- Data Rate**
  - Transmit:  Kbps
  - Receive:  Kbps
  - A vertical scale on the right side of the data rate section is marked with 10000, 1000, 100, 10, and 0.

## Test Internet Access

To test Internet access, launch your web browser and enter:

**www.plugandshare.att.com**

When you press **Enter**, the AT&T Plug&Share™ screen should appear. If it does not, see the Troubleshooting section in your User Manual (on CD-ROM).

## Problems?

If this screen does not appear when you test Internet access, or if you see the word Fail in either of the top two fields of the Wizard screen shown on page 6, please see the Troubleshooting section in your User Manual (on CD-ROM).

## See User Manual for more information

To make full use of your new wireless adapter, please see the User Manual on the enclosed CD-ROM. The manual will explain how to customize settings, share files and printers, and share your Internet connection.

AT&T Plug&Share™ Wireless USB Adapter 54 Mbps 6602G

The screenshot shows the AT&T Plug&Share website. At the top left is the AT&T logo. To its right is a search bar. Below the logo is a navigation menu with links: > AT&T Plug&Share™, Products, About Networking, and Service & Support. The main content area features a large banner with the text "AT&T Plug&Share™ DATA NETWORKING PRODUCT". Below the banner is a section titled "I WANT..." with a sub-header "to link all the computers in my home or office to enable me to share a single broadband (cable/DSL) Internet connection to:". This section lists several benefits: "Explore the Internet", "Print to a single printer", "Transfer files", "Play games", and "Share music, pictures, etc.". Below the list is the phrase "And I want it to be easy." and a "LEARN MORE" button. To the right of this section is a large image of a woman sitting on a couch using a laptop, with a wireless router in the foreground. The text "AS SIMPLE AS YOU WANT IT. AS ADVANCED AS YOU MAKE IT.™" is overlaid on the image. Below the image are three buttons: "LEARN ABOUT NETWORKING", "SEE WHAT YOU NEED", and "VIEW PRODUCTS".

Site Map | Purchase Terms & Conditions | Website Terms & Conditions | Privacy Policy  
Copyright © 2003 Advanced American Telephones. All Rights Reserved.  
AT&T and the Globe Design are trademarks of AT&T Corp., licensed to Advanced American Telephones.



For customer service, please call

**1-877-800-5400** (USA) • **1-866-669-4730** (Canada)

or visit

**[www.plugandshare.att.com](http://www.plugandshare.att.com)**

for product information and firmware upgrades as they become available

Copyright © 2004 Advanced American Telephones. All Rights Reserved.  
AT&T and the Globe Design are trademarks of AT&T Corp., licensed to Advanced  
American Telephones. All marks are trademarks of their respective corporations.  
PMGQ006602G-01